

Set up Alexa With Amazon Account Sign-In

Connection of your Amazon account to Alexa on your Lively Flip allows for personalized answers to questions like "Alexa, what is the weather forecast?" or "Alexa, what is the current time?" based on the location registered in your Amazon account.



From the *Main Menu* screen, press the **Down** arrow until "Amazon Alexa" is highlighted.
Press **Ok**.



2

On the *Welcome* to *Alexa* screen, press the **Down** arrow to highlight "Set Up Alexa." Press **Ok**.



3

The Set Up Alexa screen displays with "Sign In to Amazon" highlighted. Press Ok





The *Connecting* to Alexa... transition screen displays.



5

The Sign In to
Amazon screen
displays with
the code you
will enter on a
computer or
tablet to connect
your Amazon
account to Alexa
on your Lively Flip.



6

From your computer/tablet, go to www.amazon. com/us/code and sign into your Amazon account. If you do not have an Amazon account, you will need to create one.





Set up Alexa With Amazon Account Sign-In (con't.)



Enter the code from the screen of the Lively Flip into the Amazon registration box. Click "Continue."





The Amazon registration completion screen displays on the web page.





The Connecting to Account... screen automatically displays on the Lively Flip.



10

The Success! Alexa is connected to your Amazon account! screen displays with "Next" highlighted.
Press Ok.





The *Let's Test Alexa* screen displays.



12

The Let's Test
Alexa: Listening...
Say "Alexa,
how are you?"
transition screen
displays. Say out
loud: "Alexa, how
are you?"





Set up Alexa With Amazon Account Sign-In (con't.)



The **Let's Test Alexa: Thinking**transition screen
displays.



14

The Let's Test
Alexa: Responding
transition screen
displays while
Alexa answers your
question out loud.



15

The Let's Test Alexa screen displays again. Press the Down arrow to highlight "Skip to Using Alexa." Press Ok.



16

The *Using Alexa* screen displays. Press the **Down** arrow to highlight either "Just Ask Alexa" or "Use from Menu." Press **Ok**.



NOTE: The "Just Ask Alexa" setting allows you to ask Alexa questions after simply flipping open the phone. The "Use from Menu" setting adds additional steps of pressing the **Down** arrow to highlight "Amazon Alexa" on the *Main Menu* and pressing **Ok** before you can ask Alexa questions.



17

The Alexa successfully set up! screen displays.
The clock icon will display next to "Close." If you do not press Ok in 5 seconds, the screen will close automatically.





Set up Alexa With Amazon Account Sign-In (con't.)



If you selected the
"Just Ask Alexa"
setting, the *Main Menu* screen will
display "Ask Alexa"
in the list in place of
"Amazon Alexa."



If you selected the "Use From Menu" setting, the *Main Menu* screen will still display "Amazon Alexa" in the list.



If you'd like to use your voice to call, text and ask questions about your Lively Flip and GreatCall account, you will need to also set up the Lively skill.